



Spare Parts List Suction Line Filter SCI

Flow direction from in to out
up to 100 l/min

1. MAINTENANCE

1.1 GENERAL

Please follow the maintenance instructions!

1.2 INSTALLATION

Before fitting the filter into the system, check that the operating pressure of the system does not exceed the permitted operating pressure of the filter. Filters must be flexibly mounted and not fixed rigidly to the floor or used as a pipe support. When installing, ensure that system forces cannot be transferred to the filter. Refer to the type code label on the filter!

1.3 COMMISSIONING

Check that the correct filter element is fitted. Fit cover and tighten the cover bolts in alternation. Switch on the hydraulic system. Loosen air bleed screw (if present) max. 1 turn and vent filter. As soon as oil begins exiting at the air bleed screw, close it again firmly. If there is no air bleed screw, vent filter at an appropriate point in the system. Check the filter for leakage.

1.4 TOOLS REQUIRED FOR MAINTENANCE

SCI	Cover Fastening screw	Ext. hex. spanner key
100	M12x35	18

1.5 TORQUE VALUES FOR CLOGGING INDICATORS

On request.

2. CHANGING THE ELEMENT

2.1 REMOVING THE ELEMENT

1. Switch off hydraulic system and release filter pressure (if necessary, release the pressure in the tank).
2. Loosen bolts on the cover and lift up cover with magnetic cores.
3. Lift the filter element from the filter housing via the removal bracket and let the residual oil drip into the filter housing.
4. Examine element surface for dirt residues and larger particles since these can be an indication of damage to components.
5. Replace or clean filter element (only WPI elements can be cleaned).
6. Clean housing, cover and magnetic core.
7. Examine filter, especially sealing surfaces, for mechanical damage.
8. Check O-rings – and replace if necessary.

2.2 FITTING THE ELEMENT

1. Lubricate the sealing surfaces on the filter housing and cover, as well as the O-ring, with clean operating fluid.
2. When fitting a new filter element, check that the designation corresponds to that of the old element.
3. Insert the filter element into the filter housing and press into the O-ring flap.
4. Fit cover with magnetic core and screw on bolts by hand. Afterwards, tighten in alternation (tightening torque 40 Nm).
5. If necessary, refill hydraulic oil.
6. Switch on the hydraulic system and vent filter at a suitable point in the system or until oil exits from the air bleed screw. Close air bleed screw.
7. Check the filter for leakage.


NOTICE:

Dirt or incomplete pressure release on disassembly can lead to seizing of the housing screw-in thread.

Filter elements which cannot be cleaned must be disposed in accordance with the environmental protection regulations.

3. SPARE PARTS

3.1 SPARE PARTS DRAWING SCI



3.2 SPARE PARTS LIST SCI (specified in NBR seals)

Item	SCI 100
1.a	Cover cpl with magnetic core (mat. no.: 200299)
1.b	Cover cpl without magnetic core (mat. no.: 200300)
2.	Seal kit cpl (mat. no.: 200301) Cover: O-ring 170.82x5.33 NBR
3.	Filter element WPI-00xx-152-0062-S-N-RT xx = filtration rating

Special FKM seal design on request!

4. MAINTENANCE INSTRUCTIONS

4.1 USER INSTRUCTIONS FOR FILTERS



NOTICE

This pressure equipment must only be put into operation in conjunction with a machine or system.



NOTICE

The pressure equipment must only be used as stipulated in the operating instructions of the machine or system.



NOTICE

This pressure equipment must only be operated using hydraulic or lubricating fluid.



Caution

The operator must take appropriate action (e.g. air venting) to prevent the formation of air pockets.



Caution

Repair, maintenance work and commissioning must be carried out by specialist personnel only.

Allow the pressure equipment to cool before handling.

The guidelines of the operating instructions of the machine or system must be followed.



Danger

Caution: pressure equipment! Before any work is carried out on the pressure equipment, ensure the pressure chamber concerned (filter housing) is depressurised.



Danger

On no account may any modifications (welding, drilling, opening by force, etc.) be carried out on the pressure equipment.



NOTICE

It is the responsibility of the operator to comply with the water regulations of the country concerned.



Caution

Statutory accident prevention regulations, safety regulations and safety data sheets for fluids must be observed.



Caution

Filter housing must be earthed.



Caution

When working on, or in the vicinity of, hydraulic systems, naked flames, spark generation and smoking are forbidden.



Caution

Hydraulic oils and water-polluting fluids must not be allowed to enter the soil or watercourses or sewer systems.

Please ensure safe and environmentally friendly disposal of hydraulic oils. The relevant regulations in the country concerned with regard to ground water pollution, used oil and waste must be complied with.



Caution

Whenever work is carried out on the filter, be prepared for hot oil to escape which can cause injury or scalding as a result of its high pressure or temperature.



Danger

When using electrical clogging indicators, the electrical power supply to the system must be switched off before removing the clogging indicator connector.

Customer Information in respect of Machinery Directive 2006/42/EC

Hydraulic filters are fluid power parts/components and are therefore excluded from the scope of the Machinery Directive. They will not bear the CE mark!

Before using these components, ensure compliance with the specifications provided by HYDAC Filtertechnik GmbH in this documentation.

The specifications also contain information on the relevant essential health and safety requirements (based on Machinery Directive 2006/42/EC) that are to be applied by the user.

We hereby declare that the filters are intended to be incorporated into machinery within the terms of the Machinery Directive 2006/42/EC.

It is prohibited to put the filters into service until the device as a whole is in conformity with the provisions of the Machinery Directive.

Furthermore, our Terms of Sale and Delivery are available on our website (www.hydac.de).

SERVICE ADDRESSES

HYDAC Filtertechnik GmbH
Industriegebiet
D-66280 Sulzbach/Saar
Tel.: +49 6897 / 509-01
Fax: +49 6897 / 509-300
Internet: www.hydac.com
E-mail: filter@hydac.com

4.2 MAINTENANCE, GENERAL

This section describes maintenance work which must be carried out periodically. The operational safety and life expectancy of the filter, and whether it is ready for use, depend to a large extent on regular and careful maintenance.

4.3 MAINTENANCE MEASURES

- Spare parts are to conform to the technical requirements specified by the manufacturer. This is always guaranteed for original HYDAC spare parts.
- Keep tools, working area and equipment clean.
- After disassembling the filter, clean all parts, check for damage or wear and replace parts if necessary.
- When changing a filter element, a high level of cleanliness must be observed!

4.4 INTERVAL BETWEEN ELEMENT CHANGES

In principle we recommend that the filter element is changed after 1 year of operation at the latest. We recommend fitting the filter with a clogging indicator (visual and/or electric or electronic) to monitor the filter element.

If the clogging indicator responds, it is necessary to change or clean the filter element without delay (only WPI elements can be cleaned).

If no clogging indicator has been fitted, we recommend changing the elements at specific intervals (the frequency of changing the filter elements depends on the filter design and the conditions under which the filter is operated). If filter elements are subject to high dynamic loading it may prove necessary to change them more frequently. The same applies when the hydraulic system is commissioned or repaired or when the oil is changed.

The standard clogging indicators only respond when fluid is flowing through the filter. With electrical indicators – the signal can also be converted into a continuous display on the control panel. In this case, the continuous display must be switched off during a cold start or after changing the element.

If the clogging indicator only responds during a cold start, it is possible that the element does not need to be changed yet.

NOTICE:

The information in this brochure relates to the operating conditions and fields of application described. For fields of application and operating conditions not described, please contact the relevant technical department. All technical details are subject to change without notice.

